

2

# **Standard Operating Procedures Body Repair**

# Panel Bonding (Excluding Door Skin)

	Host	Panel	Pre	paration
--	------	-------	-----	----------

Using a grade 80 abrasive belt, remove remaining weld nugget material from host panel. Prep remaining mating flanges on host panel with a coarse Scotch-Brite<sup>™</sup> Belt to remove all adhesive, corrosion and coatings.

#### **Replacement Panel Preparation**

Remove Ecoat from replacement panel mating flange areas using Scotch-Brite<sup>™</sup> Belt or Clean N Strip disc.

#### Clean

Clean host panel and replacement panel mating flange areas with a VOC compliant surface cleaner.

#### Dry Fit Panel

Dry fit replacement panel and complete any necessary metal straightening at flanges areas. Remove panel in preparation for adhesive application.

## Weld-Thru Primer

Use Scotch-Brite<sup>™</sup> Belt to prepare metal surfaces. Clean and apply weld-thru primer to all areas requiring MIG welding.

### **Pre-Assembly NVH Replacement**

If vehicle construction necessitates, apply NVH material or foams at original locations as required.

## **Apply Bonding Adhesive**

Apply adhesive to mating flange areas on host panel and replacement panel, covering all bare metal areas. Apply an additional bead of adhesive at mating flange areas to ensure proper bond line thickness.

#### Install Replacement Panel

Install replacement panel to host panel. Clamp in place and make required welds on rear vertical seams, cosmetic joints, or where otherwise recommended by the directions for use, or the OE manufacturer. Follow recommended adhesive clamp times.

#### Adhesive Clean Up

Tool excess adhesive squeeze-out from repair area prior to curing to seal the repair. Note: Grinding to remove excess adhesive can expose bare metal, causing corrosion.

**Post-Assembly Foam Replacement** Apply foams at original locations as required.

Visit www.3MCollision.com for more SOPs and videos

	Product List				
	3M™ File Belt Sander, PN 28366				
о 	3M <sup>™</sup> Cubitron <sup>™</sup> II File Belt, grade 80+, PN 33446				
	Scotch-Brite <sup>™</sup> Durable Flex Belt, CRS, PN 64475	So			
	Scotch-Brite <sup>™</sup> Roloc <sup>™</sup> + Clean N Strip XT Disc, PN 07470	0			
	Scotch-Brite <sup>™</sup> Roloc <sup>™</sup> + Clean N Strip TR Disc, PN 07466	0			
	3M <sup>™</sup> Weld-Thru Coating II, PN 05917	重新			
	3M™ NVH Dampening Material, PN 04274				
	3M <sup>™</sup> Flexible Foam, 200mL, PN 08463				
l	3M <sup>™</sup> Panel Bonding Adhesive, 200mL, PN 08115; 200mL, PN 08116; 450mL DMS, PN 58115;				
d	50mL, PN 38315				
	3M <sup>™</sup> SMC/FRP Panel Adhesive, 200mL, PN 08219	1			





3M<sup>™</sup> Rigid Pillar Foam, 200mL, PN 08458

# **Think About Your Health**

3M<sup>™</sup> E-A-R<sup>™</sup> Skull Screws<sup>™</sup> Ear Plug, PN P1300

3M<sup>™</sup> Half Facepiece Respirator, PN 07182



3M<sup>™</sup> Lexa<sup>™</sup> Protective Eyewear, PN 15200