

PRODUCT USAGE CHECKLIST



3M™ REARVIEW MIRROR ADHESIVE | 08752

- Resistant to moisture, chemicals, vibration & impact
- Professionally mount rear view mirrors
- Excellent low temperature curing
- Flexible, excellent resistance to thermal cycles

DIRECTIONS FOR USE:

PREPARATION

A

Mark original mirror button position on the OUTSIDE of the windshield using a marker or masking tape

B

Remove mirror from mounting button. Clean any remaining adhesive from glass and mounting button using 3M™ General Purpose Adhesive Cleaner (PN 08984) and 3M™ Glass Cleaner (PN 08888)

ACCELERATOR/PRIMER

C

Surfaces should be clean and dry

D

Remove the cardboard sleeve and place on the opposite end of the ampule, exposing the wick

E

Soak the wick by squeezing the sleeve to crush the ampule. Apply the primer to both the button and marked area of the windshield

F

Allow to dry for 5 minutes

ADHESIVE

G

Tear tab at the notch on the adhesive package

H

Squeeze the adhesive from the package and apply the mirror to the mounting button

I

Place the mirror button on the glass, rotate back and forth to thoroughly spread the adhesive on the glass

J

Hold in place securely without moving for one or two minutes

K

Allow one hour for the adhesive to set before reinstalling mirror on the button



For more information on 3M Car Care products, visit www.3MCarCare.com or call (877) MMM-CARS

3Mcarcare.com

MAINTENANCE & REPAIR